## **ICON Data Product 0P: IVM Ancillary Products**

This document describes the data product for Ancillary Products for IVM Data Processing, which is in NetCDF4 format.

The IVM ancillary data file contains information on the ICON observatory as well as IVM specific information. This includes the poiniting, position, and velocity of the ICON observatory. It also includes information on the status of the observatory such as maneuvers, being in or out of the Earth's shadow, and calibrations. Pertinent information for the IVM instrument is included such as unit vectors and magnetic footpoint parameters. These files are combined with the IVM Level 1 data to produce Level 2 data. ECEF is Earth-centered, Earth-fixed reference frame. ECI is Earth-centered inertial reference frame. We use the J2000 ECI frame. LVLH is local-vertical, local-horizontal. We have two LVLH modes: normal and reverse. LVLH Normal is when the spacecraft is looking north with latitude tangent locations between ~12 S and ~42 N. LVLH Reverse is when the spacecraft is looking south with latitude tangent locations between ~42 S and ~12 N.

## **History**

Version 02, Created by IVM Ancillary Processor v2.0.4 on Thu, 08 Oct 2020, 2020-10-08T16:09:19.000 UTC

### **Dimensions**

NetCDF files contain **variables** and the **dimensions** over which those variables are defined. First, the dimensions are defined, then all variables in the file are described.

The dimensions used by the variables in this file are given below, along with nominal sizes. Note that the size may vary from file to file. For example, the "Epoch" dimension, which describes the number of time samples contained in this file, will have a varying size.

Dimension Name	Nominal Size
ЕРОСН	21600
VECTORS	3

# **Variables**

Variables in this file are listed below. First, "data" variables are described, followed by the "support\_data" variables, and finally the "metadata" variables. The variables classified as "ignore\_data" are not shown.

### support\_data

Variable Name	Description	Units	Dimensions
Epoch	Milliseconds since 1970-01-01 00:00:00 UTC at middle of measurement integration.	millisec onds	EPOCH
	Number of milliseconds since 1970-01-01 00:00:00 UTC at the middle of the measurement integration. Taken from L0P IVM data file.		
ICON_ANCILLARY_IVM_ TIME_GPS	Milliseconds since 1980-01-06 00:00:00 TAI (coincident with UTC) at middle of reading.	millisec onds	EPOCH
	Number of milliseconds since 1980-01-06 00:00:00 TAI at the middle of the measurement integration.		
ICON_ANCILLARY_IVM_ TIME_UTC	ISO 8601 formatted UTC timestamp (at middle of reading).	string	ЕРОСН
	ISO 8601 formatted UTC timestamp (at middle of reading). E.g., 2017-05-27 00:00:00.380Z		
ICON_ANCILLARY_IVM_ SC_POSITION_ECEF	ECEF Spacecraft Position	km	EPOCH, VECTORS
	Position of spacecraft in ECEF cooridinates.		
ICON_ANCILLARY_IVM_ SC_VELOCITY_ECEF	ECEF Spacecraft Velocity	m/s	EPOCH, VECTORS
	Velocity of spacecraft in ECEF cooridinates.		
ICON_ANCILLARY_IVM_ SC_POSITION_ECI	ECI Spacecraft Position	km	EPOCH, VECTORS
	Position of spacecraft in ECI, J2000, cooridinates.		
ICON_ANCILLARY_IVM_ SC_VELOCITY_ECI	ECI Spacecraft Velocity	m/s	EPOCH, VECTORS
	Velocity of spacecraft in ECI, J2000, cooridinates.		
ICON_ANCILLARY_IVM_ LATITUDE	WGS84 Latitude of Spacecraft Position (geodetic)	degree s North	EPOCH
	Geodetic latitude of spacecraft in WGS84		
ICON_ANCILLARY_IVM_ LONGITUDE	WGS84 Longitude of Spacecraft Position (geodetic)	degree s East	EPOCH
	Geodetic longitude of spacecraft in WGS84		
ICON_ANCILLARY_IVM_ ALTITUDE	WGS84 Altitude of Spacecraft Position (geodetic)	km	EPOCH
	Geodetic Altitude of Spacecraft in WGS84.		
ICON_ANCILLARY_IVM_ VNORTH	North Velocity of Spacecraft	m/s	EPOCH
	North component of the spacecraft velocity vector derived from WGS84.		

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ VEAST	East Velocity of Spacecraft  East component of the spacecraft velocity vector derived from WGS84.	m/s	EPOCH
ICON_ANCILLARY_IVM_ VDOWN	Down (Perpendicular to Local Earth Surface) Velocity of Spacecraft  Down component of the spacecraft velocity vector derived from WGS84.	m/s	EPOCH
ICON_ANCILLARY_IVM_ MAGNETIC_LATITUDE	Magnetic Latitude of Spacecraft Position  Quasi-dipole magnetic latitude of the spacecraft position. These values are obtained from passing the geodectic latitudes, longitudes, and altitudes from ICON_ANCILLARY_IVM_LATITUDE, ICON_ANCILLARY_IVM_LONGITUDE, and ICON_ANCILLARY_IVM_ALTITUDE into apexpy Python module. For details on apexpy see: https://apexpy.readthedocs.org/	degree s North	EPOCH
ICON_ANCILLARY_IVM_ MAGNETIC_LONGITUDE	Magnetic Longitude of Spacecraft Position  Quasi-dipole magnetic longitude of the spacecraft position. These values are obtained from passing the geodectic latitudes, longitudes, and altitudes from ICON_ANCILLARY_IVM_LATITUDE, ICON_ANCILLARY_IVM_LONGITUDE, and ICON_ANCILLARY_IVM_ALTITUDE into apexpy Python module. For details on apexpy see: https://apexpy.readthedocs.org/	degree s East	EPOCH
ICON_ANCILLARY_IVM_ SZA	Solar Zenith Angle at Spacecraft  Solar Zenith Angle at the spacecraft.	degree s	ЕРОСН
ICON_ANCILLARY_IVM_ LST	Local Solar Time at Spacecraft  Local Solar Time at spacecraft.	hour	ЕРОСН
ICON_ANCILLARY_IVM_ SC_XHAT_ECEF	Spacecraft X Unit Vector in ECEF (Ram Direction)  Spacecraft x-axis (nominal Ram direction) unit vector in ECEF.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ SC_YHAT_ECEF	Spacecraft Y Unit Vector in ECEF (Starboard Direction)  Spacecraft y-axis (nominal Starboard direction) unit vector in ECEF.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ SC_ZHAT_ECEF	Spacecraft Z Unit Vector in ECEF (Nadir Direction)  Spacecraft z-axis (nominal Nadir direction) unit vector in ECEF.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ SC_XHAT_ECI	Spacecraft X unit Vector in ECI (Ram Direction)  Spacecraft x-axis (nominal Ram direction) unit vector in ECI, J2000.	dimensi onless	EPOCH, VECTORS

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ SC_YHAT_ECI	Spacecraft Y Unit Vector in ECI (Starboard Direction)  Spacecraft y-axis (nominal Starboard direction) unit vector in ECI, J2000.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ SC_ZHAT_ECI	Spacecraft Z Unit Vector in ECI (Nadir Direction)  Spacecraft z-axis (nominal Nadir direction) unit vector in ECI, J2000.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ INSTRA_XHAT_ECEF	Instrument X Unit Vector in ECEF (Ram Direction)  IVM x-axis (nominal Ram direction) unit vector in ECEF.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ INSTRA_YHAT_ECEF	Instrument Y Unit Vector in ECEF (Starboard Direction)  IVM y-axis (nominal Starboard direction) unit vector in ECEF.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ INSTRA_ZHAT_ECEF	Instrument Z Unit Vector in ECEF (Nadir Direction)  IVM z-axis (nominal Nadir direction) unit vector in ECEF.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ INSTRA_XHAT_ECI	Instrument X Unit Vector in ECI (Ram Direction)  IVM x-axis (nominal Ram direction) unit vector in ECI, J2000.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ INSTRA_YHAT_ECI	Instrument Y Unit Vector in ECI (Starboard Direction)  IVM y-axis (nominal Starboard direction) unit vector in ECI, J2000.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ INSTRA_ZHAT_ECI	Instrument Z Unit Vector in ECI (Nadir Direction)  IVM z-axis (nominal Nadir direction) unit vector in ECI, J2000.	dimensi onless	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ COROTATION	ECI Earth Corotation Velocity Components in IVM Coordinates  Component of Earth's corotation velocity vector projected into the IVM instrument axes by taking the dot product of the corotation vector with the instrument's axes and multiplying the Y and Z components by negative 1 (but not the X component by convention).	m/s	EPOCH, VECTORS
ICON_ANCILLARY_IVM_ SUN_XY_PLANE_ANGLE	Angle Between Sun and IVM XY Plane  Angle between the Sun and IVM instrument XY plane.	degree s	EPOCH
ICON_ANCILLARY_IVM_ SUN_XZ_PLANE_ANGLE	Angle Between Sun and IVM XZ Plane  Angle between the Sun and IVM instrument XZ plane.	degree s	EPOCH
ICON_ANCILLARY_IVM_ MTB_STATUS	Magnetic Torquer Bar Firing Status  If the magnetic torquers are active during any part of the measurement, it is recorded as active for whole measurement.  Decoded from spacecraft housekeeping file: ICON_L0_Spacecraft_Housekeeping-MTB_2020-01-20_v01r000.CSV	binary	EPOCH

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ SUN_STATUS	Spacecraft Sun/Shadow Status Code	binary	ЕРОСН
	Data is from predictive ephemeris. 0 = spacecraft in Sun, 1 = spacecraft in Earth Shadow.		
ICON_ANCILLARY_IVM_ ORBIT_NUMBER	Orbit Number	integer	EPOCH
	Integer Orbit Number.		
ICON_ANCILLARY_IVM_ ATTITUDE_STATUS	Slew or Off-Point Status Code	binary	ЕРОСН
	Binary Coded Integer where		
	1: LVLH Normal Mode		
	2: LVLH Reverse Mode		
	4: Earth Limb Pointing		
	8: Inertial Pointing		
	16: Stellar Pointing		
	32: Attitude Slew		
	64: Conjugate Maneuver		
	128: Nadir Calibration		
	256: Lunar Calibration		
	512: Stellar Calibration		
	1024: Zero Wind Calibration		
	2048-32768: SPARE		
ICON_ANCILLARY_IVM_ SPACE_ENVIRONMENT_R	Space Environment Region Status	binary	EPOCH
EGION_STATUS	Standarized for several missions, not all codes are relevant for		
	ICON where		
	1: Earth Shadow		
	2: Lunar Shadow		
	4: Atmospheric Absorption Zone		
	8: South Atlantic Anomaly		
	16: Northern Auroral Zone		
	32: Southern Auroral Zone		
	64: Periapsis Passage		
	128: Inner & Outer Radiation Belts		
	256: Deep Plasma Sphere		
	512: Foreshock Solar Wind		
	1024: Solar Wind Beam		
	2048: High Magnetic Field		
	4096: Average Plasma Sheet		
	8192: Bowshock Crossing		
	16384: Magnetopause Crossing		
	32768: Ground Based Observatories		
	65536: 2-Day Conjunctions		
	131072: 4-Day Conjunctions		
	262144: Time Based Conjunctions		
	524288: Radial Distance Region 1		
	1048576: Orbit Outbound		
	2097152: Orbit Inbound		
	4194304: Lunar Wake		
	8388608: Magnetotail		
	16777216: Magnetosheath		
	33554432: Science		
	67108864: Low Magnetic Latitude		
	U	1	T. Control of the Con

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ A_STATUS	IVM-A Status	binary	EPOCH
A_SIATOS	Binary Coded Integer where		
	1: Earth Day View		
	2: Earth Night View		
	4: Calibration Target View		
	8: Off-target View		
	16: Sun Proximity View		
	32: Moon Proximity View		
	64: North Magnetic Footpoint View		
	128: South Magnetic Footpoint View		
	256: Science Data Collection View		
	512: Calibration Data Collection View		
	1024: RAM Proximity View		
	2048-32768: SPARE		
	Activity is what the spacecraft was commanded to do while		
	status is the spacecraft's natural state of operations. This		
	·		
	means that activity should always be used over status if they differ, but will almost always be the same.		
	differ, but will allflost always be tile same.		
ICON_ANCILLARY_IVM_	IVM-B Status	binary	EPOCH
B_STATUS			
	Binary Coded Integer where		
	1: Earth Day View		
	2: Earth Night View		
	4: Calibration Target View		
	8: Off-target View		
	16: Sun Proximity View		
	32: Moon Proximity View		
	64: North Magnetic Footpoint View		
	128: South Magnetic Footpoint View		
	256: Science Data Collection View		
	512: Calibration Data Collection View		
	1024: RAM Proximity View		
	2048-32768: SPARE		
	Activity is what the spacecraft was commanded to do while		
	status is the spacecraft's natural state of operations. This		
	means that activity should always be used over status if they		
	differ, but will almost always be the same.		
	<u> </u>		

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_	IVM-A Activity	binary	EPOCH
A_ACTIVITY			
	Binary Coded Integer where:		
	1: Earth Day View		
	2: Earth Night View		
	4: Calibration Target View		
	8: Off-target View		
	16: Sun Proximity View		
	32: Moon Proximity View		
	64: North Magnetic Footpoint View		
	128: South Magnetic Footpoint View		
	256: Science Data Collection View		
	512: Calibration Data Collection View		
	1024: RAM Proximity View		
	2048-32768: SPARE		
	Activity is what the spacecraft was commanded to do while		
	status is the spacecraft's natural state of operations. This		
	means that activity should always be used over status if they		
	differ, but will almost always be the same.		
ICON_ANCILLARY_IVM_ B_ACTIVITY	IVM-A Activity	binary	EPOCH
3_11011	Binary Coded Integer where:		
	1: Earth Day View		
	2: Earth Night View		
	4: Calibration Target View		
	8: Off-target View		
	16: Sun Proximity View		
	32: Moon Proximity View		
	•		
	64: North Magnetic Footpoint View		
	128: South Magnetic Footpoint View		
	256: Science Data Collection View		
	512: Calibration Data Collection View		
	1024: RAM Proximity View		
	2048-32768: SPARE		
	Activity is what the spacecraft was commanded to do while		
	status is the spacecraft's natural state of operations. This		
	means that activity should always be used over status if they		
	differ, but will almost always be the same.		
ICON_ANCILLARY_IVM_	Spacecraft ECEF Velocity in Instrument Coordinates	m/s	EPOCH, VECTORS
INSTRA_VELOCITY_ECE	Component of spacecraft velocity in ECEF projected into IVM		
F	instrument axes by taking the dot product of the spacecraft		
	velocity vector and the IVM axes in the ECEF frame.		
ICON_ANCILLARY_IVM_	Spacecraft ECI Velocity in Instruament Coordinates	m/s	EPOCH, VECTORS
INSTRA_VELOCITY_ECI	- I will be a second with a se		
	Component of spacecraft velocity in ECI projected into IVM		
	instrument axes by taking the dot product of the spacecraft		
	velocity vector and the IVM axes in the ECI frame.		
		+.	
ICON_ANCILLARY_IVM_ SC_MLT	Magnetic Local Time at Spacecraft	hour	EPOCH

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ SC_B_X	X Component of the Magnetic Field at the Spacecraft  X-component of the magnetic field from IGRF at the spacecarft position, expressed in the ECEF frame.	nT	EPOCH
ICON_ANCILLARY_IVM_ SC_B_Y	Y Component of the Magnetic Field at the Spacecraft  Y-component of the magnetic field from IGRF at the spacecarft position, expressed in the ECEF frame.	nT	EPOCH
ICON_ANCILLARY_IVM_ SC_B_Z	Z Component of the Magnetic Field at the Spacecraft  Z-component of the magnetic field from IGRF at the spacecarft position, expressed in the ECEF frame.	nT	EPOCH
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_LAT	Latitude of North Footpoint of Geomagnetic Line at 150 km from IGRF  Latitude location of the magnetic footpoint in the Northern Hemisphere at 150 km. These data were interpolated using a tricubic algorithm from IGRF and ephemeris data then linearly interploted to IVM times.	degree s	EPOCH
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_LON	Longitude of North Footpoint of Geomagnetic Line at 150 km from IGRF  Longitude location of the magnetic footpoint in the Northern Hemisphere at 150 km. These data were interpolated using a tricubic algorithm from IGRF and ephemeris data then linearly interploted to IVM times.	degree s	EPOCH
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_ALT	Altitude of North Footpoint of Geomagnetic Line at 150 km from IGRF  Altitude location of the magnetic footpoint in the Northern Hemisphere at 150 km. These data were interpolated using a tricubic algorithm from IGRF and ephemeris data then linearly interploted to IVM times.	km	EPOCH
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_LAT	Latitude of South Footpoint of Geomagnetic Line at 150 km from IGRF  Latitude location of the magnetic footpoint in the Southern Hemisphere at 150 km. These data were interpolated using a tricubic algorithm from IGRF and ephemeris data then linearly interploted to IVM times.	degree s	EPOCH
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_LON	Longitude of South Footpoint of Geomagnetic Line at 150 km from IGRF  Longitude location of the magnetic footpoint in the Southern Hemisphere at 150 km. These data were interpolated using a tricubic algorithm from IGRF and ephemeris data then linearly interploted to IVM times.	degree s	EPOCH

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_ALT	Altitude of South Footpoint of Geomagnetic Line at 150 km from IGRF	km	EPOCH
	Altitude location of the magnetic footpoint in the Northern Hemisphere at 150 km. These data were interpolated using a tricubic algorithm from IGRF and ephemeris data then linearly interploted to IVM times.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_ZON _ECEF_X	ECEF X-Component of Zonal Drift Directrion at Northern Footpoint	dimensi onless	EPOCH
	At the northern footpoint this is the x-component of the unit vector for zonal ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_ZON _ECEF_Y	ECEF Y-Component of Zonal Drift Directrion at Northern Footpoint	dimensi onless	EPOCH
_2022_1	At the northern footpoint this is the y-component of the unit vector for zonal ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_ZON _ECEF_Z	ECEF Z-Component of Zonal Drift Direction at Northern Footpoint	dimensi onless	EPOCH
_ ` _	At the northern footpoint this is the z-component of the unit vector for zonal ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_ZON _ECEF_X	ECEF X-Component of Zonal Drift Direction at Southern Footpoint	dimensi onless	EPOCH
	At the Southern footpoint this is the x-component of the unit vector for zonal ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_ZON ECEF_Y	ECEF Y-Component of Zonal Drift Direction at Southern Footpoint	dimensi onless	EPOCH
	At the Southern footpoint this is the y-component of the unit vector for zonal ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_ZON _ECEF_Z	ECEF Z-Component of Zonal Drift Direction at Southern Footpoint	dimensi onless	EPOCH
	At the Southern footpoint this is the z-component of the unit vector for zonal ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_MER _ECEF_X	ECEF X-Component of Meridional Drift Direction at Northern Footpoint	dimensi onless	EPOCH
_	At the northern footpoint this is the x-component of the unit vector for meridional ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_MER _ECEF_Y	ECEF Y-Component of Meridional Drift Direction at Northern Footpoint	dimensi onless	EPOCH
_	At the northern footpoint this is the y-component of the unit vector for meridional ion drifts expressed in the ECEF frame.		

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_MER _ECEF_Z	ECEF Z-Component of Meridional Drift Direction at Northern Footpoint	dimensi onless	EPOCH
	At the northern footpoint this is the z-component of the unit vector for meridional ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_MER _ECEF_X	ECEF X-Component of Meridional Drift Direction at Southern Footpoint	dimensi onless	EPOCH
	At the Southern footpoint this is the x-component of the unit vector for meridional ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_MER _ECEF_Y	ECEF Y-Component of Meridional Drift Direction at Southern Footpoint	dimensi onless	EPOCH
_ECBF_I	At the Southern footpoint this is the y-component of the unit vector for meridional ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_MER _ECEF_Z	ECEF Z-Component of Meridional Drift Direction at Southern Footpoint	dimensi onless	EPOCH
_ECEF_Z	At the Southern footpoint this is the z-component of the unit vector for meridional ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_FA_ ECEF_X	ECEF X-Component of Field Aligned Drift Direction at Northern Footpoint	dimensi onless	EPOCH
ECEF_A	At the northern footpoint this is the x-component of the unit vector for field aligned ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_FA_ ECEF_Y	ECEF Y-Component of Field Aligned Drift Direction at Northern Footpoint	dimensi onless	EPOCH
ECEF_I	At the northern footpoint this is the y-component of the unit vector for field aligned ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_FA_ ECEF_Z	ECEF Z-Component of Field Aligned Drift Direction at Northern Footpoint	dimensi onless	EPOCH
ECEF_2	At the northern footpoint this is the z-component of the unit vector for field aligned ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_FA_ ECEF_X	ECEF X-Component of Field Aligned Drift Direction at Southern Footpoint	dimensi onless	EPOCH
Hell _x	At the Southern footpoint this is the x-component of the unit vector for field aligned ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_FA_ ECEF_Y	ECEF Y-Component of Field Aligned Drift Direction at Southern Footpoint	dimensi onless	EPOCH
	At the Southern footpoint this is the y-component of the unit vector for field aligned ion drifts expressed in the ECEF frame.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_FA_ ECEF_Z	ECEF Z-Component of Field Aligned Drift Direction at Southern Footpoint	dimensi onless	EPOCH
· <u></u>	At the Southern footpoint this is the z-component of the unit vector for field aligned ion drifts expressed in the ECEF frame.		

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_ZON _DRIFT	Translating Scalars of Zonnal Ion Drifts at Northern Footpoint	dimensi onless	EPOCH
_	Scalars for translating zonal ion drifts (meridional E fields) measured at the spacecraft down to the northern footpoint.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_MER _DRIFT	Translating Scalars of Meridional Ion Drifts at Northern Footpoint	dimensi onless	EPOCH
_	Scalars for translating meridional ion drifts (zonal E fields) measured at the spacecraft down to the northern footpoint.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_ZON _DRIFT	Translating Scalars of Zonal Ion Drifts at Southern Footpoint	dimensi onless	EPOCH
_58.11.1	Scalars for translating zonal ion drifts (meridional E fields) measured at the spacecraft down to the southern footpoint.		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_MER _DRIFT	Translating Scalars of Meridional Ion Drifts at Southern Footpoint	dimensi onless	EPOCH
_	Scalars for translating meridional ion drifts (zonal E fields) measured at the spacecraft down to the southern footpoint.		
ICON_ANCILLARY_IVM_ EQU_ZON_DRIFT	Translating Scalars of Zonal Ion Drifts at Equator	dimensi onless	EPOCH
	Scalars for translating zonal ion drifts (meridional E fields) measured at the spacecraft down to the magnetic equator.		
ICON_ANCILLARY_IVM_ EQU_MER_DRIFT	Translating Scalars of Meridional Ion Drifts at Equator	dimensi onless	EPOCH
	Scalars for translating meridional ion drifts (zonal E fields) measured at the spacecraft down to the magnetic equator.		
ICON_ANCILLARY_IVM_ APEX_HEIGHT	Modified APEX Height	km	EPOCH
	Modified APEX height of the spacecraft position.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_QD_	Quasi-dipole Latitude of Northern Footpoint	degree s	EPOCH
LAT	Calculated value of quasi-dipole latitude of northern footpoint from IGRF.		
ICON_ANCILLARY_IVM_ NORTH_FOOTPOINT_QD_	Quasi-dipole Longitude of Northern Footpoint	degree s	EPOCH
LON	Calculated value of quasi-dipole longitude of northern footpoint from IGRF		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_QD_	Quasi-dipole Latitude of Southern Footpoint	degree s	EPOCH
LAT	Calculated value of quasi-dipole latitude of southern footpoint from IGRF		
ICON_ANCILLARY_IVM_ SOUTH_FOOTPOINT_QD_	Quasi-dipole Longitude of Southern Footpoint	degree s	EPOCH
LON	Calculated value of quasi-dipole longitude of southern footpoint from IGRF		

Variable Name	Description	Units	Dimensions
ICON_ANCILLARY_IVM_	Quality Flag	binary	EPOCH
QUALITY_FLAG			
	Binary Coded Integer where		
	1: STATE_NO_DATA		
	2: STATE_UNCONVERGED		
	4: STATE_LOW		
	8: STATE_MED		
	16: STATE_HIGH		
	32: AD_NO_DATA		
	64: AD_DIVERGING		
	128: AD_NOT_STARTED		
	256: AD_CONVERGING		
	512: AD_COARSE_CONVERGED		
	1024: AD_FINE_CONVERGED		
	2048-32768: SPARE		
	STATE_NO_DATA: No telemetry available for this time period.		
	States are propagated from the last valid solution.		
	STATE_UNCONVERGED: The GOODS KF solution is		
	unconverged and should not be used. States are propagated		
	from the last valid solution.		
	STATE_LOW: The GPSR solution is better than the GOODS		
	solution (The position accuracy is worse than 150 m, 1-sigma)		
	STATE_MEDIUM: The GOODS solution is better than the		
	GPSR solution (The position accuracy is better than 150 m,		
	1-sigma)		
	STATE_HIGH: The GOODS solution is better than the GPSR		
	solution, and meets its performance requirements (20 m		
	position and 0.02 m/sec velocity, 1-sigma).		
	AD_NO_DATA: No telemetry available for this time period.		
	Attitude is copied from the last valid solution.		
	AD_DIVERGING: Tolerances on the diagonal elements of the		
	covariance matrix diverging and exceeds 9.9e9 asec^2 for		
	attitude sigma and 9.9e9 asec^2/sec^2 for rate sigma or		
	negative values		
	AD_NOT_STARTED: KF has not started processing		
	AD_CONVERGING: KF is in state of updating measurements		
	and filter started to converge		
	AD_COARSE_CONVERGED: Tolerances on the diagonal		
	elements of the covariance matrix converging and below 200K		
	asec^2 for x, y and 1000K for z in tracker frame for attitude and		
	10 asec^2/sec^2 for x, y and z for rate		
	AD_FINE_CONVERGED: Tolerances on the diagonal elements		
	of the covariance matrix converging and below 1000 asec^2 for		
	x, y and z in tracker frame for attitude and 1 asec^2/sec^2 x, y		
	and z for rate		
	Naminal value of 4040, CTATE LUCLI (40) and		
	Nominal value of 1040: STATE_HIGH (16) and		
	AD_FINE_CONVERGED (1024). All values are a combination		
	of a STATE value and an AD (attitude determination) value. It is		
	up to the user to determine if data outside 1040 is usable. AD		
	values NOT AD_FINE_CONVERGED should be suspect.		
	STATE_HIGH is expected, but STATE_MED is possible during		
	maneuvers.		

#### Acknowledgement

This is a data product from the NASA Ionospheric Connection Explorer mission, an Explorer launched at 21:59:45 EDT on October 10, 2019. Guidelines for the use of this product are described in the ICON Rules of the Road (https://icon.ssl.berkeley.edu/Data)

Responsibility for the mission science falls to the Principal Investigator, Dr. Thomas Immel at UC Berkeley: Immel, T.J., England, S.L., Mende, S.B. et al. Space Sci Rev (2018) 214: 13. https://doi.org/10.1007/s11214-017-0449-2

Responsibility for the validation of the L1 data products falls to the instrument lead investigators/scientists.

- \* EUV: Dr. Eric Korpela: https://doi.org/10.1007/s11214-017-0384-2
- \* FUV: Dr. Harald Frey: https://doi.org/10.1007/s11214-017-0386-0
- \* MIGHTI: Dr. Christoph Englert : https://doi.org/10.1007/s11214-017-0358-4, and https://doi.org/10.1007/s11214-017-0374-4
- \* IVM: Dr. Roderick Heelis: https://doi.org/10.1007/s11214-017-0383-3

Responsibility for the validation of the L2 data products falls to those scientists responsible for those products.

- \* Daytime O and N2 profiles: Dr. Andrew Stephan: https://doi.org/10.1007/s11214-018-0477-6
- \* Daytime (EUV) O+ profiles: Dr. Andrew Stephan: https://doi.org/10.1007/s11214-017-0385-1
- \* Nighttime (FUV) O+ profiles: Dr. Farzad Kamalabadi : https://doi.org/10.1007/s11214-018-0502-9
- \* Neutral Wind profiles: Dr. Jonathan Makela: https://doi.org/10.1007/s11214-017-0359-3
- \* Neutral Temperature profiles: Dr. Christoph Englert: https://doi.org/10.1007/s11214-017-0434-9
- \* Ion Velocity Measurements: Dr. Russell Stoneback: https://doi.org/10.1007/s11214-017-0383-3

Responsibility for Level 4 products falls to those scientists responsible for those products.

- \* Hough Modes: Dr. Chihoko Yamashita: https://doi.org/10.1007/s11214-017-0401-5
- \* TIEGCM: Dr. Astrid Maute: https://doi.org/10.1007/s11214-017-0330-3
- \* SAMI3 : Dr. Joseph Huba : https://doi.org/10.1007/s11214-017-0415-z

Pre-production versions of all above papers are available on the ICON website. http://icon.ssl.berkeley.edu/Publications

Overall validation of the products is overseen by the ICON Project Scientist, Dr. Scott England.

NASA oversight for all products is provided by the Mission Scientist, Dr. Jeffrey Klenzing.

Users of these data should contact and acknowledge the Principal Investigator Dr. Immel and the party directly responsible for the data product (noted above) and acknowledge NASA funding for the collection of the data used in the research with the following statement: "ICON is supported by NASA's Explorers Program through contracts NNG12FA45C and NNG12FA42I"

These data are openly available as described in the ICON Data Management Plan available on the ICON website (http://icon.ssl.berkeley.edu/Data).

This document was automatically generated on 2020-10-08 09:18 using the file: ICON\_LOP\_IVM-A\_Ancillary\_2020-01-20\_v02r099.NC

Software version: ICON SDC > IVM Prime Generator 2.0.4